



MP-4815 Specifications 2nd Display 15-inch LCD panel Display Resolution LVDS 1024x768 dots XGA (24-bit) Typ. 300 cd/ m² Brightness **Backlight Lamp** Life time: min. 50,000 hours P-CAP touch (Bezel free) or Resistive Touch **Touch Panel Touch Control Board** Only for 15-inch Resistive Touch Panel (USB Interface) Speaker 3W+3W@4 ohm speaker Power Supply DC12V/3.33A/ 40W Power Adapter, 90 ~240 Vac, 50/60Hz Wall Mount VESA Mount 100x100 mm Dimension (WxHxD) 367 x 300 x 38 mm • MP-4815: 3.1 kg Weight • MP-4815 2nd Display + PA-6225: 12.6 kg Certificate **Rear I/O Ports** DC IN 1 x DC-IN port **USB** 1 x USB 2.0 port, Type B (downstream) **VGA** 1 x VGA port **Optional Integrated Moudule** Module Mounting Provides mounting holes on right side to fix other devices **Optional Integrated Devices** Camera Camera module (USB Interface) **Environment** Operating Temp. $0^{\circ}\text{C} \sim 40^{\circ}\text{C} (32^{\circ}\text{F} \sim 104^{\circ}\text{F})$ -20° C ~ 60° C (-4° F ~ 140° F) Storage Temp. Humidity 10% ~ 90%





Jumper Setting



CAUTION! Danger of explosion may occur if the battery is replaced incorrectly. Replace batteries only with the same or equivalent type recommended by the manufacturer. Dispose the used batteries according to the manufacturer's instructions.

Safety Precaution

The following messages are safety reminders on how to protect your system from damages, and thus extend the life cycle of the system.

1. Check the Line Voltage

The operating voltage for the power supply should cover the range of 9V~36V DC; otherwise, the system may be damaged.

2. Environmental Conditions

- Place your MP-4815 on a sturdy, level surface. Be sure to allow enough room on each side to have easy access.
- Avoid moving the system rapidly from a hot place to a cold place or vice versa because condensation may come from inside of the system.
- Place MP-4815 against strong vibrations, which may cause hard disk failure.

3. Handling

 Do not turn the system upside down. This may cause the hard drive to malfunction.

- Do not allow foreign objects to fall into this product.
- If water or other liquid spills into this product, unplug the power cord immediately.


4. Good Care


- When the outside of the case is stained, remove the stain with neutral washing agent with a dry cloth.
- If dust has been accumulated on the outside, remove it by using a vacuum cleaner specially made for computers.


CAUTION!


Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries accordingto the manufacturer's instructions.

WARNING!












Jumper Setting



CAUTION! Danger of explosion may occur if the battery is replaced incorrectly. Replace batteries only with the same or equivalent type recommended by the manufacturer. Dispose the used batteries according to the manufacturer's instructions.

Safety Precaution

The following messages are safety reminders on how to protect your system from damages, and thus extend the life cycle of the system.

1. Check the Line Voltage

The operating voltage for the power supply should cover the range of 9V~36V DC; otherwise, the system may be damaged.

2. Environmental Conditions

- Place your MP-4815 on a sturdy, level surface. Be sure to allow enough room on each side to have easy access.
- Avoid moving the system rapidly from a hot place to a cold place or vice versa because condensation may come from inside of the system.
- Place MP-4815 against strong vibrations, which may cause hard disk failure.

3. Handling

• Do not turn the system upside down. This may cause the hard drive to malfunciton.

- Do not allow foreign objects to fall into this product.
- If water or other liquid spills into this product, unplug the power cord immediately.


4. Good Care


- When the outside of the case is stained, remove the stain with neutral washing agent with a dry cloth.
- If dust has been accumulated on the outside, remove it by using a vacuum cleaner specially made for computers.

CAUTION!


Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries accordingto the manufacturer's instructions.

WARNING!






MP-4815 Specifications 2nd Display 15-inch LCD panel Display Resolution LVDS 1024x768 dots XGA (24-bit) Typ. $300 \text{ cd/} \text{m}^2$ Brightness **Backlight Lamp** Life time: min. 50,000 hours P-CAP touch (Bezel free) or Resistive Touch **Touch Panel Touch Control Board** Only for 15-inch Resistive Touch Panel (USB Interface) Speaker 3W+3W@4 ohm speaker Power Supply DC12V/3.33A/ 40W Power Adapter, 90 ~240 Vac, 50/60Hz Wall Mount VESA Mount 100x100 mm Dimension (WxHxD) 367 x 300 x 38 mm Weight • MP-4815: 3.1 kg • MP-4815 2nd Display + PA-6722: 11 kg Certificate **Rear I/O Ports** DC IN 1 x DC-IN port USB 1 x USB 2.0 port, Type B (downstream) **VGA** 1 x VGA port **Optional Integrated Moudule** Module Mounting Provides mounting holes on right side to fix other devices **Optional Integrated Devices** Camera module (USB Interface) **Environment** Operating Temp. $0^{\circ}\text{C} \sim 40^{\circ}\text{C} (32^{\circ}\text{F} \sim 104^{\circ}\text{F})$ -20° C ~ 60° C (-4° F ~ 140° F) Storage Temp. Humidity 10% ~ 90%





Jumper Setting



CAUTION! Danger of explosion may occur if the battery is replaced incorrectly. Replace batteries only with the same or equivalent type recommended by the manufacturer. Dispose the used batteries according to the manufacturer's instructions.

Safety Precaution

The following messages are safety reminders on how to protect your system from damages, and thus extend the life cycle of the system.


- 1. Check the Line Voltage
 - The operating voltage for the power supply should cover the range of 9V~36V DC; otherwise, the system may be damaged.
- 2. Environmental Conditions
 - Place your MP-4815 on a sturdy, level surface. Be sure to allow enough room on each side to have easy access.
 - Avoid moving the system rapidly from a hot place to a cold place or vice versa because condensation may come from inside of the system.
 - Place MP-4815 against strong vibrations, which may cause hard disk failure.
- 3. Handling
 - Do not turn the system upside down. This may cause the hard drive to malfunction.


- Do not allow foreign objects to fall into this product.
- If water or other liquid spills into this product, unplug the power cord immediately.
- 4. Good Care
 - When the outside of the case is stained, remove the stain with neutral washing agent with a dry cloth.
 - If dust has been accumulated on the outside, remove it by using a vacuum cleaner specially made for computers.


CAUTION!


Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries accordingto the manufacturer's instructions.

WARNING!












Jumper Setting



CAUTION! Danger of explosion may occur if the battery is replaced incorrectly. Replace batteries only with the same or equivalent type recommended by the manufacturer. Dispose the used batteries according to the manufacturer's instructions.

Safety Precaution

The following messages are safety reminders on how to protect your system from damages, and thus extend the life cycle of the system.

- 1. Check the Line Voltage
 - The operating voltage for the power supply should cover the range of 9V~36V DC; otherwise, the system may be damaged.
- 2. Environmental Conditions
 - Place your MP-4815 on a sturdy, level surface. Be sure to allow enough room on each side to have easy access.
 - Avoid moving the system rapidly from a hot place to a cold place or vice versa because condensation may come from inside of the system.
 - Place MP-4815 against strong vibrations, which may cause hard disk failure.
- 3. Handling
 - Do not turn the system upside down. This may cause the hard drive to malfunction.

- Do not allow foreign objects to fall into this product.
- If water or other liquid spills into this product, unplug the power cord immediately.
- 4. Good Care
 - When the outside of the case is stained, remove the stain with neutral washing agent with a dry cloth.
 - If dust has been accumulated on the outside, remove it by using a vacuum cleaner specially made for computers.

CAUTION!

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries accordingto the manufacturer's instructions.

WARNING!