


	Line Out	1 x Phone Jack
	Cash Drawer	1 x RJ11 (+12V/24V selectable)
	DC-in	1 x 4pin DC Power Jack
Peripheral	Customer Display	VFD, 20 columns and 2 lines, each column is 5 X 7 dots
	MSR & iButton	JIS-I or II,ISO Track1+2+3(PS/2 interface)
	2 nd Display	8" or 10.4" LCD
	Fingerprint	8-bit grayscale, reader
Display	Resolution	1024 x 768
	Brightness	250 cd/m ² LED Backlight
	Touch Screen	Bezel-Free 5-wire Analog Resistive or Projected Capacitive
Environment	EMC & Safety	CE / FCC
	Operating Temp.	0 ~ 35°C
	Storage Temp.	-20 ~ 60°C
	Humidity	20 ~ 90%



<sup>Opeate the PA-6225 in strong vibration may cause hard disk failure.
Do not place the system too close to any radio-active device.</sup>

• Always shutdown the energing system before turning off t

COM1 select	[Disabled]
COM2 select	[Disabled]
COM3 select	[Disabled]
Cash drawer	[Cash drawer 12V]
Advanced	
COM1 select	[5V]
	[5V] [12V]
COM1 select COM2 select COM3 select	

Advanced

• Always shutdown the operating system before turning off the power.

3. Handling

- Avoid placing heavy objects on the top of the system.
- Do not turn the system upside down. This may cause the hard drive to malfunction.
- Do not allow any objects to fall into this product.
- If water or other liquid spills into this product, unplug the power cord immediately.

4. Good Care

- When the outside case gets stained, remove the stains using neutral washing agent with a dry cloth.
- Never use strong agents such as benzene and thinner to clean the case surface.
- If heavy stains are present, moisten a cloth with diluted neutral washing agent or alcohol and then wipe thoroughly with a dry cloth.
- If dust is accumulated on the case surface, remove it using a special vacuum cleaner for computers.
- Do not replace the motherboard battery by yourself, or serious damage may occur.

All Rights Reserved. Copyright 2014

Radio-active device may cause signal interference.